

Technical Newsletter

#tnl2010-0009e

1 / 1



Dicing Saws – Notification of Change of Replacement Interval of the Spindle Carbon Brush When Using N₂ Gas as a Substitute for Clean Air

Applicable models

All the models of DISCO's dicing saws are applicable.

Cautions When Using N₂ Gas as a Substitute for Clean Air

CAUTION

When using N₂ gas as a substitute for clean air, replace the spindle carbon brush in the interval appropriate to the actual wear status, regardless of the recommended replacement interval (365 days) of the carbon brush

Supplying N₂ gas to the spindle may result in unusual wear of the carbon brush.

- For other cautions when using N₂ Gas, see the Safety Manual.

Inquiries

Please contact your DISCO sales representative or DISCO service office if you have any questions regarding this matter.
